# 3.5Inch MSX Micro FDD System FD-03/FD-031

## TECHNICAL SUMMARY

<b>PREFACE</b>		

The FD-03 is a 3.5-inch micro floppy disk drive system for the MSX computer system. The system connection configuration is illustrated in Figure 1-1. Throughout this manual, the names shown in Figure 1-1 are used.

This system can store 360K byte of data per drive unit and can operate on two combined drives (drive A and drive B). Drives A and B are connected with slot of the MSX computer through the interface cartridge.


Power supplied to drive A is provided by AC adapter, as shown in Figure 1-1. This power supply is adequate to supply power to the additional drive B.

### **CONTENTS**

- 1. 3.5-INCH FLOPPY DISK DRIVE SYSTEM (FD-030, FD-031)
- 2. OPERATIONAL PRINCIPLE OF MECHANICAL (DRIVE A, DRIVE B)
- 3. SPECIFICATION OF ELECTRIC CIRCUIT (CARTRIDGE, DRIVE A, DRIVE B)
- 4. TROUBLESHOOTING
- 5. ADJUSTMENT

# 1 3.5-INCH FLOPPY DISK DRIVE SYSTEM (FD-030, FD-031)

#### Overview



#### Specifications

Usable disk

Storage capacity

3.5-inch single sided MF-1DD (135 TPI)

Unformatted; 500K bytes Formatted; 360K bytes

512 byte/sector

9 sector/track 1 track/cylinder

80 track/disk

Recording density

Track density
Total number of cylinders

Total number of tracks

Recording method Data transfer rate

Average rotation wait time

Access time

8187 bit/inch 135 track/inch

80

80

MFM modulation 250K bit/sec

100 msec

Average; 664 msec Between track; 24 msec

	Drive A	Drive B	Cartridge
Power supply	Ac adaptor	+5V supplied	+5V supplied from
	7.5V 1A	from Main unit	MSX cartridge slot
Power	TYP. 4.5W	TYP. 2.5W	About 1W
consumption	MAX. 6.0W	MAX. 3.5W	

Working temperature

37°F - 67°F


Maximum outside dimension

132 mm x 207 mm x 64 mm (W x L x H)

Weight


1.2 kg

## Block diagram



## 2 OPERATIONAL PRINCIPLE OF MECHANICAL (DRIVE A, DRIVE B)

#### DISK DRIVE CONFIGURATION




The hub is made of magnetic metal and has two holes as shown in Figure 2-1. The middle one receives the spindle and the other one is for the drive pin.

When a floppy disk is inserted, the hub is attracted by a magnetic force. The spindle rotates clockwise to move the drive pin as shown Figure 2-2 and Figure 2-3. Pin contacts a and b, c and d and is positioned.


The spindle is rotated at 300 rpm.

#### READ/WRITE HEAD CONFIGURATION

The Read/Write head is always in contact with the disk. The surface of the head is designed to minimize wear on the head and disk. This will maximize the data read signal from the disk.



#### HEAD POSITIONING MECHANISM




The head is mounted on the carriage and positioned with the step motor and lead screw. When one pulse is applied to the step motor, lead screw rotates by 15 and the head moves 0.046875 mm. Four steps of the step motor is equal to a travel for one track (0.1875 mm).

#### **DISK PAD MECHANISM**


The Read/Write head contacts the disk by means of a pad which presses on the disk as shown in Figure 2-6.

The pad is designed to maximize the data read signal by means of a pad arm spring, mounted between the pad arm and the carriage.




#### **DISK REMOVAL MECHANISM**


With the disk inserted, a disk holder presses the shutter lever. The shutter lever rotates to open the shutter of disk. When a disk is inserted deep into the holder, the shutter lever is locked with the shutter stopper and it pushes the slide plate stopper at the same time.



The slide plate stopper rotates to unlock the slide plate. The slide plate slides under spring tension. The disk holder snaps down and the disk is chucked in place.




By pushing the Eject lever, the disk holder raises and the disk claw holder pushes the shutter stopper to unlock the shutter lever. The tension of the shutter lever spring, cause the disk to be ejected.




#### WRITE PROTECT TAB (WRITE PROTECT SENSOR)

The disk has a slide type write protector. By sliding this to the open window, the disk is inhibited to write. This drive system has a write protect detect switch which detects whether or not the window is open.




#### **INDEX SENSOR**

This drive system requires a start mark (index signal) at read/write time. The index detection sensor detects the index signal via the notch in the disk support.



#### **MEDIA SENSOR**

When the disk is inserted and chucked, the disk detection switch is pushed by the disk. This sensor detects whether or not the disk has been mounted.



#### RESTORE (ACTION FOR RETURNING THE HEAD TO HOME POSITION)

This drive system returns the head to Tr0 (home position) when the power is ON. Tr0 is positioned when a portion of the carriage closes a slit in the Tr0 detection sensor.


# 3 SPECIFICATION OF ELECTRIC CIRCUIT (CARTRIDGE, DRIVE A, DRIVE B)

#### CONFIGURATION OF ELECTRIC CIRCUIT

The electronic components can be roughly divided into Cartridge, Power Supply and Drive.

The cartridge performs control of the drive and the interface with MSX computer system.

The power provides supplies +5 V and +12 V to the drive. The drive part performs the control of the motor, write of the head and waveform adjustment of read signal.



#### **CARTRIDGE**

(The circuit diagram of the cartridge is shown in the attached Figure 3-2.)

The circuit of the cartridge consists of PROM, FDC, VFO I/O port Decoder circuit and I/O buffer.

The description of parts as follows:

#### 1) PROM (M5L27256)

This is a PROM compatible with Intel 27256 and incorporates the drive control program, MSX-Disk-Basic and MSX-DOS.

The CPU of the MSX computer system can read this ROM through the cartridge bus.

#### 2) FDC (M5W1793-02P)

This is a floppy disk controller compatible with Western Digital FD1793-02. This performs MFM modulation and demodulation of data, control of step motor, monitoring of drive sensor.

#### 3) VFO (SED9420C)

This is a VFO type data separator, manufactured by SUWA SEIKOSHA. This waveform adjustment of the read signal from the disk and convert it into window signal and regenerative read data signal. This prevents the decrease of read margin caused by change of rotation speed of DC motor and peak shift of read signal. The CLOCK of FDC is supplied from this IC.

#### 4) I/O PORT (74LS175, 74LS365, 74LS74)

74LS175 is an output port. This port can control switching of the drive and ON/OFF of the DC motor.
74LS365 and 74LS74 are input ports. They detect the presence of the disk, whether or not the disk has been changed, or presence of data request of FDC.

#### 5) DECODER (74LS30, 74LS138, 74LS32)

It allocates the proper address to PROM, FDC and I/O port. ROM is addressed 4000h -7FBFh and FDC 7FC0h - 7FDFh and BFC0h - BFDFh, I/O port 7FE0h - 7FFFh and BFE0h - BFFFh.

#### 6) I/O BUFFER (72LS14, 7406 DTC114Y)


The output signal to drive is provided from the open collector and the input signal from drive can be received in the Schmidt trigger. The input signal is pulled up by  $1K\Omega$  because the drive side output is the open collector.


#### **POWER SUPPLY**

The circuit diagram of the power supply for drive A is illustrated in Figure 3-3. The circuit diagram for the drive B illustrated in Figure 3-4.

The power supply of drive A consists of the constant voltage circuit which produces +5 Volts, from the AC adapter. The DC-DC converter circuit which converts +5 Volts, into +12 Volts and the signal pathes between the drive and cartridge.

Power supply of the drive B is the same as that of drive A mentioned above. The power for drive B is supplied from drive A.






#### DRIVE (DRIVE BOARD)

As shown in Figure 3-5 block diagram, this board consists of an interface, read/write circuit, DC motor drive, stepper drive, LED and each sensor inputs.

The circuit diagram of the drive board is shown in the attached Figure 3-6. Terminal

names and functions of the IC M51017AP for read/write/control are shown in Table 3-1.



#### 1) Interface section

This exchanges data between the cartridge board and the drive board through a buffer.

#### 2) Read/write circuit section

Write circuit, read circuit and time chart during a read function are shown in Figure 3-7 to Figure 3-9 respectively.

#### \* During writing


When WG (Write gate) signal is sent from the cartridge board it is an active (LOW), the write circuit enables the write mode and sends current to the head to write data on the media. R7 in Figure 3-7 sets the value of write current.


#### \* During reading

Data picked up by the R/W head is amplifiered by a amplifier and the high-frequency noise is removed through a filter. Waveform adjustment is then passed through a differentiator to detect the position of the peak value a "RD" pulse is generated at zero-cross point of the output.

After comparator output, the timed main filter is provided to absorb saddle ( $\triangle T$  of Figure 3-9).

In the circuit diagram (Figure 3-8), R11 and C8 set the time constant of the timer main filter and R12 and C9 set the width of RD pulse.








Table 3-1 (a) M51017AP pin indication

Terminal Number	Name	Function
33	Vcc	5V Power Supply
19	V <sub>BB</sub>	12V Power Supply
21 - 25	GND	Ground (Analog system)
51 - 55	GND	Ground (Digital system)
18	CT.0	Terminal to supply WRITE current and ERASE
		current at WRITE
16. 17	READ 0	Input/output terminal for READ/WRITE signal
		to HEAD
12. 13	OFFSET DECOUPLING	Controls a gain of READ amplifier
	(GAIN ADJ)	
10. 11	AMPLIFIER OUTPUT	Output terminal for preamplifier
8. 9	ACTIVE DIFFEREN-	Input terminal for differenciator
	CIATOR INPUT	
6. 7	DIFFERENCIATOR	Terminal to adjust a peak shift externally
	COMPONENT	
4. 5	M/M COMPONENT	Sets a time constant of monostable multi-
		vibrator to prevent a wrong output of READ
		data.


Terminal	Name	Function		
Number	rumo	r unction		
2. 3	M/M/ COMPONENT	Sets a time constant of monostable multi-		
		vibrator to set the output pulse width of		
		READ data.		
27	WRITE CURRENT ADJ	Terminal to set WRITE current		
44	INUSE LED	"L", when DRIVE SELECT (47 pin) is at "L".		
46	INDEX	"H", when INDEX SENSOR (41 pin) is at "L".		
57	TRACK 0	"L", when TRACK 0 SENSOR (41 pin) is at "L"		
		and pulse output "A" (39 pin) of a stepping		
		motor drive is at "H".		
58	WR PROTECT	"L", when WPT SENSOR (42 pin) is at "L".		
59	RD DATA	Output terminal for READ data		
		OFF at WRITE and ERASE.		
40	STEPPER DRIVE	A		
	PULSE	_ Generates a two-phase exited drive		
39		A pulse.		
		1 step and 1 pulse when STEP SWITCH		
38		B (30 pin) is at "L", 1 step and 2 pulse		
		when it is at "H".		
37		В		
47	DRIVE SELECT	Terminal to indicate the select state of a		
10	DIDECTION	drive unit. Selectable at "L".		
48	DIRECTION	Input terminal to specify the head travel		
		direction.		
		"L" for a center direction, "H" for a phe-		
40	CMDD	ripheral direction		
49	STEP	Input terminal to generate a pulse to drive		
F0	IIID DAMA	the head. Blocked at WRITE.		
50	WR DATA	Input terminal for record data.		
56	WR GATE	Becomes the record effective with "L" input.		
43	INDEX SENSOR	Indicates the rotation state and accept		
		input every rotation. INDEX (46 pin) is at		
42	WPT SENSOR	"L" when INDEX SENSOR is at "H".		
42	WF1 SENSOR	Input terminal to decide whether or not		
		writing data on the disk is possible. WR		
		PROTECT (58 pin) is at "L" when WPT SENSOR is at "L".		
41	TRACK 0 SENSOR			
41	MOGNING U MORMI	Input terminal to indicate the head is on TRACK 0. TRACK 0 (57 pin) is at "L" when		
		TRACK 0. TRACK 0 (57 pm) is at "L" when TRACK 0 SENSOR is at "H".		
35	RESET	Input terminal for POWER ON RESET. Initia-		
	MINIT	lises each M/M at "H".		
30	STEP			
	DILL	Input terminal to select 1 step and 1 pulse or 1 step		
		or r steh		

#### 3) DC motor drive (Spindle motor circuit)

The circuit diagram is shown in Figure 3-10.

"MON" signal sent from the cartridge causes Q10 to toggle ON or OFF, and the DC motor to start or stop.

Q11 is always OFF and is turned ON if overcurrent flows, this limits the current into the motor.




#### 4) Step motor drive


The circuit diagram is shown in Figure 3-11 and the timing chart is shown in Figure 3-12.

This converts  $\overline{\text{STEP}}$  and  $\overline{\text{DIR}}$  signals sent from the cartridge board. The signal for driving bipolar through a stepper control in IC (M51017AP) passes the current to the STEP motor via the drive circuit.

L4 and C13 in the circuit diagram are filters for removing noise.

When the drive is not selected, the gate input prevents the current from flowing to the STEP motor.






#### 5) Sensor input section

The circuit diagram is shown in Figure 3-13.


It inputs, "INDEX" and "Track 0" Write protect signals from each sensor and send it to IC (M51017AP), through invertor IC's as shown.

In the IC, the gate input is made so that the signal is passed to the cartridge only when DS (drive select) is active. "Media In" signal is applied direct, without any inversion.



Description of each sensor

\* INDEX Signal for detecting the rotation starting point of media, it is output according to the timing chart shown in Figure 3-14.



- \* Track 0
- Indicates R/W head is on Track 0.
- \* Write protect
- Detects the state of the write protect notch and inhibits data from being written.
- from being written.
- \* Media In Checks whether or not media is inserted in the drive.

#### 6) LED

POWER LED is illuminated when the power is "ON", and the "IN USE LED ON" when the drive is selected.

#### **GENERAL PROCEDURE**

This section explains the basic procedure of the control program for the drive, locate in the cartridge ROM.

#### 1) Drive select, motor ON/OFF

Drive selection is made by activating DS0 or DS1.
Both drives may not be selected at the same time.
Motor "ON" is made before selection of the drive. After motor ON, about one second is used as wait time.
After finishing access of the disk, the motor stops in about three seconds.

#### 2) Restore

This signal will restore the head position with reference to the track 0 sensor. The head is first moved inward till the "Track 0" signal becomes non-active. Then it is moved outward and stopped when the "Track 0" signal becomes active.

#### 3) Seek

Seek moves the head to a destination track, controlled by the step motor. After setting the PIRC signal to an appropriate polarity, a proper number of 4  $\mu s$  wide pulses are output to the STEP signal in a 6 ms interval.

#### 4) Read

This signal allows data to be read from the disk. When the Read command is passed to FDC, the FDC performs MFM modulation of the RD signal from the drive and control program receives to stores the signal in RAM of MSX computer system.

#### 5) Write

This signal allows data to be written onto the disk. The program sends the Write command to FDC and the FDC receives data complying with its request. The FDC performs MFM modulation of data and outputs a WD signal to the drive. The drive section receives this data and stores it on the disk.